



DEXTER  
LAUNDRY

# WCAD Washer Soft Reset

## Step 1- Remove top panel

## Step 2 – Turn power Off to machine

## Step 3 – Locate program button on PCB

- Program button is located on the top of the PCB control at the front of the machine

## Step 4 – Performing soft reset

- Push and hold the programming button on PCB, power the machine up while holding the programming button.
- The display will show **Set** on the screen, release the programming button. The display will now go to the vend price.
- The soft reset of the machine has been completed.

