

DDAD Troubleshooting The Back Draft Damper

Back draft damper stuck.

- Access the back draft damper from the top of exhaust stack.
 There will be on damper for each pocket.
- The outside damper is for the lower dryer, the inside damper is for the upper dryer.
- Check for and remove lint buildup in exhaust above dampers.
 Remove any other foreign materials from exhaust duct as well.
- Check to ensure that dampers move up and down freely without resistance.
- If further access is needed it can be attained by removing control box and exhaust duct cover to access the lower damper.



