



DEXTER.
LAUNDRY

Replacing The Pressure Switch

Step 1 - Turn power off to machine

Step 2 – Remove top panel off of machine

Step 3 -Locate and remove pressure switch

- Pressure switch is located in the rear of the control box on the left hand side.
- To remove pressure switch, disconnect wire harness, remove the two screws holding pressure switch to the mounting bracket, remove pressure switch tube from the bottom of pressure switch.

Step 4 – Install new pressure switch

- Install new pressure switch in reverse order.

