




DEXTER[®]
LAUNDRY



WC Series Vended Washers
Schematics 50Hz


T-300 WC0300XA-39 230VAC 50Hz Wiring Diagram




INFORMATIVE 6102-018-207A
 WIRING DIAGRAM 230V-1PH-50HZ

P/N 9506-723-001PR
 20 LB COIN, VV DRIVE, 230V
 WITH START AND STOP BUTTONS
 NO COIN ACCEPTOR, 24V ACTUATORS


T-300 WC0300XA-39 230VAC 50Hz Wiring Schematic




T-350 WC0350XA-39 230VAC 50Hz Wiring Diagram




T-350 WC0350XA-39 230VAC 50Hz Wiring Schematic




T-400 WC0400XA-39 230VAC 50Hz Wiring Diagram



T-400 WC0400XA-39 230VAC 50Hz Wiring Schematic



T-750 WC0750XA-39 230VAC 50Hz Wiring Diagram




INFORMATIVE 6102-018-212


WIRING DIAGRAM 230V-1PH-50HZ

P/N 9506-534-001A
 SOLER COIN EXPRESS V.F. DRIVE 230V
 NO COIN ACCEPTOR, 24V ACTUATORS


T-750 WC0750XA-39 230VAC 50Hz Wiring Schematic




T-900 WC0900XA-39 230VAC 50Hz Wiring Schematic



T-950 WC0950XA-39 230VAC 50Hz Wiring Schematic




T-1200 WC1200XA-39 230VAC 50Hz Wiring Diagram



INFORMATIVE 6102-018-215A
WIRING DIAGRAM 230V-1PH-50HZ

P/N 9506-737-001PR
80 LB COIN, VF DRIVE, 230V
WITH START AND STOP BUTTONS
NO COIN ACCEPTOR, 24V ACTUATORS

T-1200 WC1200XA-39 230VAC 50Hz Wiring Schematic



T-1450 WC1450XA-39 230VAC 50Hz Wiring Schematic

