



DEXTER
LAUNDRY

STACK DRYER TROUBLESHOOTING THE PCB CONTROLLER

Control board.

- Check all harnesses for proper connections.
- Check Green (Ground) wire to ensure proper grounding.
- Check the upper and lower door close lights by opening and closing the doors.
- Check battery on control board for proper installation.
- Check incoming voltage on the black wire.
- To test for a bad membrane switch, close both doors and press the program switch. If the control is good, both pockets should run a 5 minute test cycle.

