

REPLACING THE PRESSURE SWITCH

- **Step 1** - Turn power off to machine
- **Step 2** – Remove top panel from the machine
- **Step 3** -**Locate and remove pressure switch**
 - The pressure switch is located in the rear of the control box on the left-hand side.
 - To remove the pressure switch, disconnect wire harness, remove the two screws holding pressure switch to the mounting bracket, remove the pressure switch tube from the bottom of pressure switch.
- **Step 4** – **Install new pressure switch**
 - Install the new pressure switch in reverse order.

