DEXTER®
LAUNDRY

# WCAD-Series Vended Washers
# Prevenative Maintenance

# Preventative Maintenance

## Daily

**Step 1:** Clean the top and the cabinet to remove residue.

**Step 2:** Clean the soap dispenser and soap lid

**Step 3:** Check the drain for leaking and proper draining.

**Step 4:** Check the loading door for leaks.

**Step 5:** Clean the door seal of all foreign material.

**Step 6:** Leave the loading door open to aerate the washer when not in use.

## Monthly

**Step 1:** Clean with dry and clean compressed air through optical coin acceptor to remove dust and lint.

## Quarterly

Make sure the power is disconnected before making the following checks.

**Step 1:** Check the drive belt for wear and proper tension.

**Step 2:** Clean lint and other foreign material from around drive motor.

**Step 3:** Check all water connections for leaks.

**Step 4:** Wipe and clean the inside of the washer and check all electrical components for moisture and dust.

**Step 5:** Remove and clean water inlet hose filters. Replace if necessary.

**Step 6:** After any service always replace all panels before reconnecting electrical power.

## Biannually

**Step 1:** Clean the fan on the bottom of the VFD with dry and clean compressed air.

## Annually

**Step 1:** Inspect all wire connections for tightness

**Step 2:** Inspect and check the tightness of the mounting bolts securing the washer to base frame.